## HEMICAL



## Test Method

Apply 3 drops of each chemical reagent on the surface of BETACRYL® solid surfaces

Expose the sample for 16 hours; covered with glass plate and uncovered

Check the surface and scrub the surface with a wet scotch-brite® pad and bleaching cleanser such as ajax®

## Test Result

The residue from the following chemical reagents can be removed with a wet scotch-brite® pad and bleaching cleanser.

Acetic acid (10%) Acetone **Ammonia** Ammonium hydroxide (5,28%)

Amyl acetate Amyl alcohol B-4 body conditioner Ball point pen

Benzene Bleach (household type)

Blood Butyl alcohol

Calcium thiocyanate (78%) Carbon disulfide

Carbon tetrachloride Cigarette (nicotine and tar)

Citric acid (10%) Coffee

Cooking oils Cottonseed oil Cupra ammonia Dishwashing liquid/pow-

ders Ethanol Ethyl acetate Ethyl ether Formaldehde Gasoline Gentian violet Grape juice Hair dyes

Household soaps Hydrochloric acid (20,30,37%)

Hydrogen peroxide lodine (1%)

Ketchup Lemon juice Lipstick

Mercurochrome (2%)

Methanol

Methyl ethyl ketone Methyl orange (1%) Methyl red (1%) Mineral oil Mustard Nail polish \_ Naphthalene N-hexane

Olive oil Pencil lead Perchloric acid

Permanent marker pen

Shoe polish

Soapless detergents Sodium bisultate Sodium hydroxide solution (5,10,25,40%) Sodium sulfate

Soy sauce Sugar (sucrose)

Sulfuric acid (25,33,60%) Sulfuric acid (25,33,60%)

Tetrahydrofuran Toluene Tomato juice

Urea (6%) Uric acid Vinegar Washable inks

Wine *Xvlene* Zinc Chloride

The following chemical reagents may affect the surface with more serious damage, requiring sanding for complete removal.

Frequent and/or prolonged exposure to these reagents should be avoided.

Acetic acid (90,98%) Acid drain cleansers Chlorobenzene

Chloroform (100%) Chromic trioxide acid

Cresol Dioxahe Ethyl acetate

Equalizing mix (50/50) Film developer

Formic acid (50,90%)

**Furfural** 

Glacial acetic acid Hydrofluoric acid (48%) Luralite mix (50/50)

Methylehe chloride based products such as paint removers, brush cleansers and

some metal cleansers Nitric acid (25,30,70%) Phenol (40,85%)

Phosphoric acid (75,90%) Sulfuric acid (77,96%) Trichloroacetic acid (10,50%)

3M Avagardm D